ISO BOARDS WITH SPLINED BRACKETS 7916

FITS:ALL VARIOUS APPLICATIONS, REQUIRES SPLINED ADAPTER MOUNTS, SOLD SEPARATELY

PART #	INCLUDED	
601916L	1	Left Footboard Mount Assembly
607916R	1	Right Footboard Mount Assembly
907916	1	Hardware Kit Includes:
	2	5/16"-18 X 7/8" Socket Head Cap Screw
	1	Anti-Seize
307916	1	Installation Instructions

THANK YOU FOR CHOOSING KURYAKYN!

TOOLS SUGGESTED

1/4" and 5/16" Allen Wrenches

CAUTION!

These boards are not intended as a step. Passenger and rider should be aware that they should be used as a footrest only.

PROCEDURE

STEP 1 Remove the OEM pegs from the bike.

STEP 2 Separate the footboard from the mount by removing the 3/8"–16" socket head cap screw from the wide end of the board and the 1/4"–20" socket head cap screw from the narrow end. Be very careful not to lose the detent ball and spring located between the board and mount. See PIC.1.

STEP 3 Loosely attach your adapter (sold separately) to the footboard mount with the 5/16"–18 X 7/8" Socket Head Cap Screw provided as shown in PIC.2. Shown is the splined adapter, Küryakyn P/N 8813 for Kawasaki. Your adapter may look slightly different but must have the splines on the inner face of the adapter to properly mate with the splines on the footboard bracket.

-cont.-

PIC.1

PIC.2

CUSTOMER SERVICE

877.370.3604 (toll free)

INSTALLATION QUESTIONS

techsupport@kuryakyn.com
or call 715.247.2983

LIMITED WARRANTY

Küryakyn warrants that any Küryakyn products sold hereunder, shall be free of defects in materials and workmanship for a period of one (1) year from the date of purchase by the consumer excepting the following provisions:

- Küryakyn shall have no obligation in the event the customer is unable to provide a receipt showing the date the customer purchased the product(s).
- The product must be properly installed, maintained and operated under normal conditions.
- Küryakyn makes no warranty, expressed or implied, with respect to any gold plated products.
- Küryakyn shall not be liable for any consequential and incidental damages, including labor and paint, resulting from failure of a Küryakyn product, failure to deliver, delay in delivery, delivery in nonconforming condition, or for any breech of contract or duty between Küryakyn and a customer.
- Küryakyn products are often intended for use in specific applications. Küryakyn makes no warranty if a Küryakyn product is used in applications other than intended.
- Küryakyn electrical products are warranted for one (1) year from the date of purchase by the consumer. Components of Küryakyn products containing L.E.D.s will be warranted for defects in materials and workmanship for 3 years from the date of purchase.
- Küryakyn makes no warranty of any kind in regard to other manufacturer's products distributed by Küryakyn. Küryakyn will pass on all warranties made by the manufacturer and where possible, will expedite the claim on behalf of the customer, but ultimately, responsibility for disposition of the warranty claim lies with the manufacturer.

ABOUT OUR CATALOG

You'll find all our innovations for H-D, GL and Metric Cruisers in our annual catalogs. Order online today–select the "CATALOGS" icon. Each Küryakyn™ product comes with a Proof-of-Purchase good for a complimentary catalog. Details in packaging.

Be sure to ask your local dealer about other Küryakyn products, the motorcycle parts and accessories designed for riders by riders.

©2005 Küryakyn USA™ All Rights reserved.

STEP 4 Mount the adapter to the bike using the OEM peg mounting hardware. Determine the angle that will provide you the most comfort without interfering with other nearby components. Fully tighten the 5/16"–18 X 7/8" Socket Head Cap Screw securing the footboard mount to the adapter.

STEP 5 Place a dab of grease in the recess where the detent ball seats in the footboard mount to help hold it in place during reassembly. Attach the footboard to the footboard mount in reverse order as they were disassembled in STEP 2.

Ride On!